


ASSEMBLY INSTRUCTIONS

Triple Swing Arm Floor Lamp

Item # S1200



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Screw the bottom of part (3) into the top of part (2).
2. Screw the top of part (1) into the bottom of part (2).
3. Pull the wire until taut.
4. Put the harp (4) into the harp saddle by squeezing both sides of the harp.
5. Remove finial (6) from the harp (4) .
6. Place lamp shade (6) onto the bolt to secure shade to the harp.
7. Insert bulb (NOT INCLUDED) into the socket.
8. Plug lamp cord into wall outlet.
9. ADJUSTMENT INSTRUCTIONS:
 - 1) Loosen adjustable key found on lamp stem.
 - 2) Adjust height to desired position.
 - 3) Tighten key.

